


## Power Cube Assistant

THE SOFTWARE POWER CUBE ASSISTANT IS A DEVICE PROVIDING USEFUL ADVICE FOR COIL OPTIMISATION


- Before starting the program, ensure that the RS-232 PC serial port is connected to the Power cube by means of one of the following cables:
  - > 1) SERIAL CABLE 1m (code 19623)
  - > 2) SERIAL CABLE 3m (code 23243)
- To start the program, double click on the icon with the left button of the mouse
- Place the piece to be heated inside the coil
- Press the BEGIN TEST button first and then the END TEST button



- 1 **INPUT:** indication of the Power Cube input values.
  - **V Line:** input voltage
  - **TEMP:** cooling water temperature
- 2 **OUTPUT:** Indication of the Power Cube output values
  - **V COIL:** coil voltage
  - **I SUPPLY:** supply current
  - **I OUT:** output current
  - **POWER:** power
  - **Frequency:** working frequency
- 3 **EXPERT ADVICE:** Assessment of the working cycle state from the beginning 3a to the end 3b of the test

The screenshot shows the main control interface. On the left, there are sections for INPUT (V LINE, TEMP), OUTPUT (V COIL, I SUPPLY, I OUT, POWER, Frequency), and EXPERT ADVICE. The EXPERT ADVICE section displays a green message: "Coil ok. The system is working with the max. active power. The current control type is recommended." Below this are "BEGIN TEST" (3a) and "END TEST" (3b) buttons. On the right, there is a graph showing I SUPPLY (%) vs V COIL (%).


- 4 The trace persistence on the diagram is activated by pressing the **TRACE MEMORY ON/OFF** button 4a
- 5 The trace previously imprinted is deleted by pressing the **CLEAR TRACES** button



- 6 **POWER - %:** modifies the value of the set power
- 7 **START:** start of Head heating
- 8 **STOP:** end of Head heating
- 9 Head **ON** indicator

The CONTROL panel features a "POWER" slider set to 99 (6), "START" (7) and "STOP" (8) buttons, and a "GENERATOR DISPLAY" section showing "WORKING TIME - h" (000516) and "HEATING TIME - h" (000022). A green indicator light (9) is visible on the left. Buttons for "Exit" and "AUTO" are also present.

- 10 **LIMIT:** optimal working area that can be achieved following the expert's advice 3



COSTRUZIONI ELETTRONICHE INDUSTRIALI AUTOMATISMI

Zona Ind.le 54/G, 52041 Vicinomaggo - Arezzo (ITALY)  
 Tel. +39 0575-4181 Fax +39 0575-418287  
 E-mail: powercube@ceia-spa.com

www.ceia.net

DP040K0012v1000UK